Test Equipment Solutions Datasheet

Test Equipment Solutions Ltd specialise in the second user sale, rental and distribution of quality test & measurement (T&M) equipment. We stock all major equipment types such as spectrum analyzers, signal generators, oscilloscopes, power meters, logic analysers etc from all the major suppliers such as Agilent, Tektronix, Anritsu and Rohde & Schwarz.

We are focused at the professional end of the marketplace, primarily working with customers for whom high performance, quality and service are key, whilst realising the cost savings that second user equipment offers. As such, we fully test & refurbish equipment in our in-house, traceable Lab. Items are supplied with manuals, accessories and typically a full no-quibble 2 year warranty. Our staff have extensive backgrounds in T&M, totalling over 150 years of combined experience, which enables us to deliver industry-leading service and support. We endeavour to be customer focused in every way right down to the detail, such as offering free delivery on sales, covering the cost of warranty returns BOTH ways (plus supplying a loan unit, if available) and supplying a free business tool with every order.

As well as the headline benefit of cost saving, second user offers shorter lead times, higher reliability and multivendor solutions. Rental, of course, is ideal for shorter term needs and offers fast delivery, flexibility, try-before-you-buy, zero capital expenditure, lower risk and off balance sheet accounting. Both second user and rental improve the key business measure of Return On Capital Employed.

We are based near Heathrow Airport in the UK from where we supply test equipment worldwide. Our facility incorporates Sales, Support, Admin, Logistics and our own in-house Lab.

All products supplied by Test Equipment Solutions include:

- No-quibble parts & labour warranty (we provide transport for UK mainland addresses).
- Free loan equipment during warranty repair, if available.
- Full electrical, mechanical and safety refurbishment in our in-house Lab.
- Certificate of Conformance (calibration available on request).
- Manuals and accessories required for normal operation.
- Free insured delivery to your UK mainland address (sales).
- Support from our team of seasoned Test & Measurement engineers.
- ISO9001 quality assurance.

Test equipment Solutions Ltd Unit 8 Elder Way Waterside Drive Langley Berkshire SL3 6EP

T: +44 (0)1753 596000 F: +44 (0)1753 596001

Email: info@TestEquipmentHQ.com Web: www.TestEquipmentHQ.com





Spectrum Master[™] High Performance Handheld Spectrum Analyzer

MS2723B

9 kHz to 13 GHz

Introduction

Anritsu's high performance handheld spectrum analyzer provides the wireless professional the performance needed for the most demanding measurements in harsh RF and physical environments. Whether it is for spectrum monitoring, broadcast proofing, interference analysis, RF and microwave measurements, regulatory compliance, or Wi-Fi and wireless network measurements, the Spectrum Master is the ideal instrument to making fast and reliable measurements.

Spectrum and Interference Analyzer Highlights

- Measure: Occupied Bandwidth, Channel Power, ACPR, C/I
- Interference Analyzer: Spectrogram, Signal Strength, RSSI
- Dynamic Range: > 101 dB in 1 Hz RBW
- DANL: -159 dBm in 1 Hz RBW
- Phase Noise: –95 dBc/Hz @ 10 kHz offset at 1 GHz
- Frequency Accuracy: \leq ± 25 ppb with GPS On

Capabilities and Functional Highlights

- LTE, GSM/EDGE
- W-CDMA/HSDPA
- TD-SCDMA/HSDPA
- · CDMA, EV-DO
- WiMAX Fixed, Mobile
- AM/FM/SSB Demodulator
- Zero-span IF Output
- · Gated Sweep
- GPS tagging of stored traces
- Internal Preamplifier standard

- 1 Hz to 3 MHz Resolution Bandwidth (RBW)
- Traces: Normal, Max Hold, Min Hold, Average, # of Averages
- Detectors: Peak, Negative, Sample, Quasi-peak, and true RMS
- Markers: 6, each with a Delta Marker, or 1 Reference with 6 Deltas
- Limit Lines: up to 40 segments with one-button envelope creation
- Trace Save-on-Event: crossing limit line or sweep complete
- High Accuracy Power Meter
- 4, 6, 8, 18 GHz USB Sensors
- · Channel Scanner
- 8.4" Display

- < 5 minute warm-up time
- 2.3 hour battery operation time
- Ethernet/USB Data Transfer
- MST Remote Access Tool



Spectrum Master™ MS2723B Spectrum Analyzer

Handheld Size: 315 mm x 211 mm x 77 mm (12.4 in x 8.3 in x 3.0 in), Lightweight: 3.4 kg (7.5 lbs)



Spectrum Analyzer

Measurements	
Smart Measurements	Field Strength (uses antenna calibration tables to measure dBm/m^2 or $dBmV/m$)
	Occupied Bandwidth (measures 99% to 1% power channel of a signal)
	Channel Power (measures the total power in a specified bandwidth)
	ACPR (adjacent channel power ratio)
	AM/FM/SSB Demodulation (wide/narrow FM, upper/lower SSB), (audio out only)
	C/I (carrier-to-interference ratio)
	Emission Mask (recall limit lines as emission mask)
Setup Parameters	
Frequency	Center/Start/Stop, Span, Frequency Step, Signal Standard, Channel #
Amplitude	Reference Level (RL), Scale, Attenuation Auto/Level, RL Offset, Pre-Amp On/Off, Detection
Span	Span, Span Up/Down (1-2-5), Full Span, Zero Span, Last Span
Bandwidth	RBW, Auto RBW, VBW, Auto VBW, RBW/VBW, Span/RBW
File	Save, Recall, Delete, Directory Management
Save/Recall	Setups, Measurements, Limit Lines, Screen Shots Jpeg (save only), Save-on-Event
Save-on-Event	Crossing Limit Line, Sweep Complete, Save-then-Stop, Clear All
Delete	Selected File, All Measurements, All Mode Files, All Content
Directory Management	Sort Method (Name/Type/Date), Ascend/Descend, Internal/USB CF, Copy
Application Options	Impedance (50 Ω , 75 Ω , Other)
Sweep Functions	
Sweep	Single/Continuous, Manual Trigger, Res <mark>et, Detection</mark> , Minimum Sweep Time, Trigger Typ Gated Sweep (see Option 0090)
Detection	Peak, RMS, Negative, Sample, Quasi-peak
Triggers	Free Run, External, Video, Change Position, Manual
Trace Functions	50 78th
Traces	Up to three Traces (A, B, C), View/Blank, Write/Hold, Trace A/B/C Operations
Trace A Operations	Normal, Max Hold, Min Hold, Average, # of Averages, (always the live trace)
Trace B Operations	$A \rightarrow B, B \leftarrow \rightarrow C, Max Hold, Min Hold$
Trace C Operations	$A \rightarrow C$, $B \longleftrightarrow C$, Max Hold, Min Hold, $A - B \rightarrow C$, $B - A \rightarrow C$, Relative Reference (dB), Scal
Marker Functions	GL . III
Markers	Markers 1-6 each with a Delta Marker, or Marker 1 Reference with Six Delta Markers,
	Marker Table (On/Off), All Markers Off
Marker Types	Style (Fixed/Tracking), Noise Marker, Frequency Counter Marker
Marker Auto-Position	Peak Search, Next Peak (Right/Left), Peak Threshold %, Set Marker to Channel,
	Marker Frequency to Center, Delta Marker to Span, Marker to Reference Level
Marker Table	1-6 markers frequency and amplitude plus delta markers frequency offset and amplitude
Limit Line Functions	Crisco (a)
Limit Lines	Upper/Lower, On/Off, Edit, Move, Envelope, Advanced, Limit Alarm, Default Limit
Limit Line Edit	Frequency, Amplitude, Add Point, Add Vertical, Delete Point, Next Point Left/Right
Limit Line Move	To Current Center Frequency, By dB or Hz, To Marker 1, Offset from Marker 1
Limit Line Envelope	Create Envelope, Update Amplitude, Number of Points (41), Offset, Shape Square/Slope
Limit Line Advanced	Type (Absolute/Relative), Mirror, Save/Recall
Frequency	
Frequency Range	9 kHz to 13 GHz (usable to 0 Hz), Preamp 100 kHz to 4 GHz
Tuning Resolution	1 Hz
Frequency Reference	Aging: ± 1.0 ppm/10 years
5	Accuracy: ± 0.3 ppm (25 °C ±25 °C) + aging
Frequency Span	10 Hz to 13 GHz including zero span
Span Accuracy	Same as frequency reference accuracy
Sweep Time	10 µs to 600 seconds in zero span, autoset in non-zero span
Sweep Time Accuracy	± 2% in zero span
Bandwidth	
Resolution Bandwidth (RBW)	1 Hz to 3 MHz in 1–3 sequence ± 10% (1 MHz max in zero-span) (–3 dB bandwidth)
Video Bandwidth (VBW)	1 Hz to 3 MHz in 1–3 sequence (–3 dB bandwidth)
RBW with Quasi-Peak Detection	200 Hz, 9 KHz, 120 kHz (-6 dB bandwidth)
VBW with Quasi-Peak Detection	Auto VBW is On, RBW/VBW = 1

Spectrum Analyzer (cont	inuea)
Spectral Purity	
SSB Phase Noise	-95 dBc/Hz @ 10, 20 and 30 kHz offset from carrier
	-97 dBc/Hz @ 100 kHz offset from carrier
	-105 dBc/Hz @ 1 MHz offset from carrier -120 dBc/Hz @ 10 MHz offset from carrier
Amplitude Ranges	120 039,12 @ 10 1 11 2 01 300 1 01 11 01 1 01 1 01 1
Dynamic Range	> 101 dB @ 2.4 GHz, 2/3 (TOI-DANL) in 1 Hz RBW
Measurement Range	DANL to +30 dBm
Display Range	1 to 15 dB/div in 1 dB steps, ten divisions displayed
Reference Level Range	-120 dBm to +30 dBm
Attenuator Resolution	0 to 65 dB, 5.0 dB steps
Amplitude Units	Log Scale Modes: dBm, dBV, dBmv, dBμV
	Linear Scale Modes: nV, μV, mV, V, kV, nW, μW, mW, W, kW
Amplitude Accuracy (single sine wave input	< Ref level, and > DANL, auto attenuation, 50 Ω Source)
20 °C to 30 °C	± 1.3 dB, after 30 minute warm-up
	> 4 GHz add ± 1.4 dB
-10 °C to 50 °C	Add ± 1.2 dB, after 60 minute warm-up
	4S detection, Ref Level = -20 dBm for preamp Off and -50 dBm for preamp On)
(DANL in 1 Hz RBW, 0 dB attenuation)	Preamp Off
10 MHz to 4 GHz	-139 dBm
> 4 GHz to 10 GHz	-136 dBm
> 10 GHz to 13 GHz	-130 dBm
> 13 GHz to 20 GHz	-136 dBm
	Preamp On
10 MHz to 1 GHz	-159 dBm
> 1 GHz to 3 GHz	-156 dBm
> 3 GHz to 4 GHz	-154 dBm
Spurs	-139 dBm -136 dBm -136 dBm -136 dBm Preamp On -159 dBm -156 dBm -154 dBm
Residual Spurs	Preamp Off (RF input terminated, 0 dB input attenuation)
	-90 dBm Preamp On (RF input terminated, 0 dB input attenuation)
	-100 dBm
Input-Related Spur <mark>ious</mark>	(0 dB attenuation, -30 dBm input, span < 1.7 GHz, carrier offset > 4.5 MHz)
	+60 dBc, -70 dBc typical
Exceptions	650 dBc @ 3275 MHz
Third-Order Intercept (TOI)	
	(-20 dBm tones 100 kHz apart, -20 dBm Ref level, 0 dB input attenuation, preamp Off
2.4 GHz	+12 dBm
50 MHz to 500 MHz	> +6 dBm typical
> 500 MHz to 2000 MHz	> +8 dBm typical
> 2000 MHz to 6000 MHz	> +10 dBm typical
> 6000 MHz to 20000 MHz	> +12 dBm typical
Second Harmonic Distortion	
	Preamp Off
50 MHz to 500 MHz	-50 dBc
> 500 MHz to 800 MHz	-45 dBc
> 800 MHz to 3000 MHz	-60 dBc
>3000 MHz	-80 dBc

1:5:1 typical

> 10 dB input attenuation

GPS Receiver Option (Option 0031) (includes antenna)

Setup On/Off, GPS Info GPS Time/Location Indicator Time, Latitude, Longitude and Altitude on display Time, Latitude, Longitude and Altitude with trace storage High Frequency Accuracy Spectrum Analyzer, Interference Analyzer, Signal Analyzer when GPS Antenna is connected <±25 ppb with GPS On, 3 minutes after satellite lock in selected mode <±50 ppb for 3 days, 0 °C to 50 °C ambient temperature GPS Lock - after antenna is disconnected Connector BNC, female, reverse polarity



High Accuracy Power Meter (Option 0019) (Requires external USB Power Sensor(s))

	Amplitude	Maximum, Minimum, Offset,	Relative On/Off, Units, Auto S	cale
	Average	# of Running Averages, Max Hold		
	Zero/Cal	Zero On/Off, Cal Factor (Cent	ter Frequency, Signal Standard	i)
	Limits	Limit On/Off, Limit Upper/Lov	wer	
Power Sensor Model	PSN50	MA24104A	MA24106A	MA24108/18/26A
Description	High Accuracy	Inline High	High Accuracy	Microwave
	RF Power Sensor	Power Sensor	RF Power Sensor	USB Power Sensor
Frequency Range	50 MHz to 6 GHz	600 MHz to 4 GHz	50 MHz to 6 GHz	10 MHz to 8 GHz (MA24108A) 10 MHz to 18 GHz (MA24118A) 10 MHz to 26 GHz (MA24126A)
Connector	Type N(m), 50 Ω	Type N(m), 50 Ω	Type N(m), 50 Ω	Type N(m), 50 Ω (MA24108/18A) Type K(m), 50 Ω (MA24126A)
Dynamic Range	-30 dBm to +20 dBm	+3 dBm to +51.76 dBm	-40 dBm to +23 dBm	-40 dBm to +20 dBm
	(.001 mW to 100 mW)	(2 mW to 150 W)	(0.1 µW to 200 mW)	(0.1 μ W to 100 mW)
VBW	100 Hz	100 Hz	100 Hz	50 kHz
Measurand	True-RMS	True-RMS	-40 dBm to +23 dBm (0.1 µW to 200 mW) 100 Hz True-RMS	True-RMS, Slot Power, Burst Average Power
Measurement Uncertainty	± 0.16 dB ¹	± 0.17 dB ²	\pm 0.16 dB 1	\pm 0.18 dB ³
Datasheet (for complete specifications)	11410-00414	11410-00483	11410-00424	11410-00504
Notes:	zero mismatch errors.	t uncertainty (0 °C to 50 °C) for po	_	

 ²⁾ Expanded uncertainty with K=2 for power measurements of a CW signal greater than +20 dBm with a matched load. Measurement results referenced to the input side of the sensor.
 3) Expanded uncertainty with K=2 for power measurements of a CW signal greater than -20 dBm with zero mismatch errors.



Interference Analyzer (Option 0025)

Measurements Spectrum

Field Strength Occupied Bandwidth

Channel Power

Adjacent Channel Power (ACPR)

AM/FM/SSB Demodulation (Wide/Narrow FM, Upper/Lower SSB), (audio out only)

Carrier-to-Interference ratio (C/I)
Spectrogram (Collect data up to one week)

Signal Strength (Gives visual and aural indication of signal strength)
Received Signal Strength Indicator (RSSI) (collect data up to one week)

Gives visual and aural indication of signal strength

Signal ID (up to 12 signals)

Center Frequency

Bandwidth

Signal Type (FM, GSM, W-CDMA, CDMA, Wi-Fi)

Closest Channel Number
Number of Carriers

Application Options Signal-to-Nose Ratio (SNR) > 10 dB

Impedance (50 Ω , 75 Ω , Other)

lutald

Channel Scanner (Option 0027)

Number of Channels 1 to 20 Channels (Power Levels)

Measurements Graph/Table, Max Hold (On/5 sec/Off), Frequency/Channel, Current/Maximum, Dual Color Scanner Scan Channels, Scan Frequencies, Scan Customer List, Scan Script Master™

Amplitude Reference Level, Scale

Custom Scan Signal Standard, Channel, # of Channels, Channel Step Size, Custom Scan

Application Options Impedance (50 Ω , 75 Ω , Other)

Gated Sweep (Option 0090)

Mode Spectrum Analyzer, Sweep

Trigger External TTL

Setup Gated Sweep (On/Off)

Gate Polarity (Rising, Falling)
Gate Delay (0 to 65 ms typical)

Gate Length (1 μ s to 65 ms typical)

Zero Span Time

Zero Span IF Output (Option 0089)

Mode Spectrum Analyzer/Span/Zero Span

Center Frequency 37.8 MHz

IF Bandwidth 7 MHz, 10 MHz, 16 MHz, typical

Output Power Level -20 dBm to -45 dBm Typical given:

RF Input = +30 dBm to -43 dBm with Preamp OFF -40 dBm to -60 dBm with Preamp ON

Reference Level set at RF Input Level

Auto RF Attenuation

RF Attenuation Auto

Connector BNC female



GSM/GPRS/EDGE Signal Analyzers (Options 0040, 0041)

		Measu	irements	
RF (Option 0040)		odulation ion 0041)	Over-the-Air (OTA)	Pass/Fail (User Editable)
Channel Spectrum Channel Power Occupied Bandwidth Burst Power Average Burst Power Frequency Error Modulation Type BSIC (NCC, BCC) Multi-channel Spectrum Power vs. Time (Frame/Slot) Channel Power Occupied Bandwidth Burst Power Average Burst Power Frequency Error	Phase Error EVM Origin Offset C/I Modulation Typ Magnitude Erro BSIC (NCC, BC	pe pr	There are no additional OTA Measurements. RF Measurements and Demodulation can be made OTA	Measurements Channel Power Occupied Bandwidth Burst Power Average Burst power Frequency Error Phase Error EVM Origin Offset C/I Magnitude Error Script Master™
Modulation Type BSIC (NCC, BCC)			4	
Setup Parameters				
GSM,	'EDGE Select	Auto, GSM, EDGE		Decreased to see and Channel
	Frequency	, ,	andard, Channel #, Closest Channel	, Decrement/Increment Channel
	Amplitude		to Range, Adjust Range s, Trigger Sweep	OM
	Sweep	Single/Continuou	s, Trigger Sweep	×.
	Save/Recall	Setup, Measurem	ent, Screen Shot (save only), to Int	ernal/External Memory
Measurement Sum	mary Screen	Overall Measuren	nents	
RF Measurements (Option 00	940)		of Course	
Fre	quency Error	± 10 Hz + time b	oase error, 99% confidence level	
Occupie	d Bandwidth	Bandwidth within	which 99% of the power transmitte	ed on a single channel lies
Burst	: Power Error	± 1.5 dB, ± 1 dB	typical, (-50 dBm to +20 dBm)	
Demodulation (Option 0041)			16 com	
GSMK Modulation Quality Measurem	(RMS Phase) ent Accuracy	± 1 deg	Sentho.	
Residual E	error (GSMK)	1 deg	P.M.	
8 PSK Modulation Q Measurem	Quality (EVM) ent Accuracy	± 1.5%	typical, (-50 dBm to +20 dBm)	
Residual E	Error (8 PSK)	2.5%		



W-CDMA/HSDPA Signal Analyzers (Options 0044, 0045 or 0065, 0035)

		Meas	urements	
RF (Option 0044)	Demodulati (Option 0045 or		Over-the-Air (OTA) (Option 0035)	Pass/Fail (User Editable)
Band Spectrum Channel Spectrum Channel Power Occupied Bandwidth Peak-to-Average Power Spectral Emission Mask Single carrier ACLR Multi-carrier ACLR RF Summary	Code Domain Power Graph P-CPICH Power Channel Power Noise Floor EVM Carrier Feed Through Peak Code Domain Error Carrier Frequency Frequency Error Control Channel Power Abs/Rel/Delta Power CPICH, P-CCPCH S-CCPCH, PICH P-SCH, S-SCH HSDPA Power vs. Time Constellation Code Domain Power Table Code, Status EVM, Modulation Type Power, Code Utilization Power Amplifier Capacity Codogram Modulation Summary		Scrambling Code Scanner (Six) Scrambling Codes CPICH E _C /I _O E _C Pilot Dominance OTA Total Power Multipath Scanner (Six) Six Multipaths Tau Distance RSCP Relative Power Multipath Power	Measurements Max Output Power Frequency Error EVM CPICH Occupied Bandwidth Spectral Mask ACLR PCDE P-CCPCH S-CCPCH Code Spread 3 PICH Code 128 Script Master™ Test Models 1 (16), (32), (64) 2 3 (16), (32) 4 (+CPICH), (-CIPCH) 5 (2 HS), (4 HS), (8 HS)
Setup Parameters	Trouville Trouvi	111	le of kito com	
Scrambling (Code, Threshold Auto,	Manual	or up.co	
			c, S-CCPCH Spread, S-CCPCH Code CPICH Power, Frequency Error Ave	
Maximum S	preading Factor 256, 5	512	ent Edi	
	Frequency Cente	r, Sig <mark>nal</mark> St	andard, Channel #, Closest Chanr	el, Decrement/Increment Channel
	Amplitude Scale/	Division, P	ower Offset, Auto Range, Adjust R	ange, Units (dBm/Watts)
	Marker Six Ma	rke <mark>rs, T</mark> ab	le On/Off	
	Sweep Single	/Continuou	ıs, Trigger Sweep	
	Save/Recall Setup	. Measuren	nent, Screen Shot (save only), to I	internal/External Memory
Measurement Su	mmary Sc <mark>ree</mark> ns Overa	l Measurer	ments, RF Measurements, Signal Q	Quality Measurements
RF Measurements (Option		dhis		
	211	•	dB typical, (temperature range 1	5 °C to 35 °C)
'	dwidth Accuracy ± 100			
Adjacent Channel Leaka			0.8 dB @ 5 MHz/10 MHz offset, typica ± 1.0 dB @ 5 MHz/10 MHz offset, t	
Demodulation (Option 004		·		ypical, Dalla VII
• •	•		(Codecs: AMR 4.75, 5.9, 7.4, 12	2 khns DTX 7.4 12.2 khns)
		16 QAM, 6		- Nopo, DIN 1.7, 12,2 NUpo)
HJL	,	-	:VM ≤ 25%	
	•	typical	= 2070	
Code	e Domain Power ± 0.5	dB for cod	e channel power > -25 dB, (test model 1), 16, 32 DCPH (tes	t model 2, 3)
CPICH	(dBm) Accuracy ± 0.8	dB typical		
Over-the-Air (OTA) Measu	rements (Option 0035)			
-	g Code Scanner Six str		rambling Codes	

Six multipaths' power relative to strongest pilot

Multipath Scanner



cdmaOne/CDMA2000 1X Signal Analyzers (Option 0042, 0043, 0033)

		Meas	urements	
RF (Option 0042)		nodulation otion 43)	Over-the-Air (OTA) (Option 33)	Pass/Fail (User Editable)
Channel Spectrum Channel Power Occupied Bandwidth Peak-to-Average Power Spectral Emission Mask Multi-carrier ACPR RF Summary	Code Domain Pilot Power Channel Pov Noise Floor Rho Carrier Feed Tau RMS Phase Frequency E Abs/Rel/ Pov Pilot Page Sync Q Page Code Domain Code Status Power Multiple Cod Code Utiliza Modulation Su	ver I Through Error irror wer Power Table les	Pilot Scanner (Nine) PN E_{c}/I_{0} Tau Pilot Power Channel Power Pilot Dominance Multipath Scanner (Six) E_{c}/I_{0} Tau Channel Power Multipath Power Limit Test - 10 Tests Averaged Rho Adjusted Rho Multipath Pilot Dominance Pilot Power Pass/Fail Status	Measurements Channel Power Occupied Bandwidth Peak-to-Average Power Spectral Mask Test Frequency Error Channel Frequency Frequency error Pilot Power Noise Floor Rho Carrier Feed Through Tau RMS Phase Error Code Utilization Measured PN Pilot Dominance Multipath Power
Setup Parameters				
	PN Setup		ow MHz Tandard Change # Closest Change	pe (Auto, Manual), PN Offset
	Walsh Codes	64, 128	, Re	coll
	asurement Speed	Fast, Normal, Sl	ow	3.
	al Trigger Polarity	Rising, Falling	Samel	
	umber of Carriers	1 to 5	at for quit	
C	Carrier Bandwidth	1.23, 1.24, 1.25	MHz	
	Frequency		turidard, Charmer II, Closest Charmer	, becrement merement enamer
	Amplitude		Power Offset, Auto Range, Adjust Ran	nge, Units (dBm/Watts)
	Sweep		us, Trigger Sweep	
	Save/Recall		nent, Screen Shot (save only), to In	·
	ummary Screens	Overall Measure	ments, RF Measurements, Signal Qu	ality Measurements
RF Measurements (Optio		COM	IPIT	
	l Power Accuracy	± 1.5 dB, ± 1.0	dB typical, (RF input -50 dBm to +2	0 dBm)
Demodulation (Option 00	•	lality les		
	Frequency Error	#10 Hz + time	base error, 99% confidence level (in	slow mode)
	Rho Accuracy	± 0.005, for Rho		
	Residual Rho	> 0.995, typical	, > 0.99 maximum, (RF input -50 dE	3m to +20 dBm)
	PN Offset	1 x 64 chips		
Pilo	t Power Accuracy	± 1.0 dB typical	, relative to channel power	
	Tau	± 0.5 μs typical,	± 1.0 μs maximum	
Over-the-Air (OTA) Meas	urements (Option	0033)		
	Pilot Scanner	Nine strongest p	ilots	
M	Iultipath Scanner	Six multipaths' p	power relative to strongest pilot	

Average of ten tests compared to limit

Limit Test



CDMA2000 1xEV-DO Signal Analyzers (Option 0062, 0063, 0034)

		Measu	urements	
RF (Option 0062)		odulation ion 0063)	Over-the-Air (OTA) (Option 0034)	Pass/Fail (User Editable)
Channel Spectrum Channel Power Occupied Bandwidth Peak-to-Average Power Power vs. Time Pilot & MAC Power Channel Power Frequency Error Idle Activity On/Off Ratio Spectral Emission Mask Multi-carrier ACPR RF Summary	Pilot & MAC Channel Pow Frequency E Rho Pilot Rho Overall Data Modula Noise Floor	ver rror ition nain Power Table tion main Power Power ition ata CDP ita CDP	Pilot Scanner (Nine) PN E _C /I _O Tau Pilot Power Channel Power Pilot Dominance Mulitpath Scanner (Six) E _C /I _O Tau Channel Power Multipath Power	Measurements Channel Power Occupied Bandwidth Peak-to-Average Power Carrier Frequency Frequency Error Spectral Mask Noise Floor Pilot Power RMS Phase Error Tau Code Utilization Measured PN Pilot Dominance Mulitpath Power
Setup Parameters				l
	PN Setup	PN Trigger (No Tr	MHz andard, Channel #, Closest Chanrower Offset, Auto Range, Adjust R s, Trigger Sweep	Type (Auto, Manual), PN Offset
	Walsh Codes	64, 128	Rentom	
Mea	surement Speed	Fast, Normal, Slo	w or no.	
Externa	l Trigger Polarity	Rising, Falling	Salenenti	
	Slot Type	Auto, Active, Idle	for wight	
Nu	mber of Carriers	1 to 5	sent atta	
Ca	arrier Bandwidth	1.23, 1.24, 1.25	MHz MHz	
	Frequency	Center, Signal St	andard, Channel #, Closest Chanr	nel, Decrement/Increment Channel
	Amplitude	Scale/Division, Po	ower Offset, Auto Range, Adjust R	ange, Units (dBm/Watts)
	Sweep	Single/Continuou	s, Trigger Sweep	
	Save/Recall	20 00	nent, Screen Shot (save only), to 1	·
Measurement Su		Overall Measuren	nents, RF Measurements, Signal C	Quality Measurements
RF Measurements (Option		JS Kal		
	Power Accuracy	± 1.5 dB, ± 1.0 d	dB typical, (RF input –50 dBm to -	+20 dBm)
Demodulation (Option 00	-			
	OO Compatibility	Rev 0 and Rev A		
	Frequency Error		pase error, 99% confidence level	
	Rho Accuracy	± 0.01, for Rho >		1Pm to 120 dPm\
	Residual Rho		> 0.99, maximum (RF input –50 c	וווס +בט מטווו)
B11 -	PN Offset	Within 1 x 64 chi	•	
Pilot	Power Accuracy		relative to channel power	
Owner than All (OTT) 15	Tau		± 1.0 μs maximum	
Over-the-Air (OTA) Meası	• •	•		
	Pilot Scanner	Nine strongest pi	lots	
R.A.	ultimath Casman	C:		

Six multipaths' power relative to strongest pilot

Multipath Scanner



LTE Signal Analyzers (Options 0541, 0542, 0546)

		Meas	urements	
RF (Option 0541)		odulation tion 0542)	Over-the-Air (OTA) (Option 0546)	Pass/Fail (User Editable)
Channel Spectrum Channel Power Occupied Bandwidth ACPR RF Summary	Constellation Reference S Sync Signal EVM Frequency Carrier Frec Cell ID Sector ID Group ID Control Chann RS P-SS S-SS PBCH PCFICH Modulation	Error quency nel Power	Synch Signal Power (Six Strongest) Power Cell ID Sector ID Group ID Dominance	Pass Fail All Pass/Fail RF Pass Fail Demod Measurements Channel Power Occupied Bandwidth ACLR Frequency Error Carrier Frequency Dominance EVM (peak) EVM (rms) RS Power SS Power P-SS Power P-SS Power P-SS Power P-SC Power
Setup Parameters				
	Bandwidth	10 MHz	Ola	ental com
	Span	1.4, 3, 5, 10, 15	, 20, 30 MHz	is con
	Frame Length	2.5, 5.0, 10.0 ms	sec	nel, Decrement/Increment Channel
	Frequency Amplitude		ower Offset, Auto Range, Adjust R	
	Sweep		is, Trigger Sweep	ange
	Save/Recall		nent, Screen Shot (save only), to	Internal/External Memorv
Measurement S	ummary Screens		nents, RF Measurements, Signal C	
RF Measurements (Optio	· ·		185 8:	<u> </u>
RF Channe	el Power Accuracy	± 1.5 dB, ± 1.0	dB typical, (RF input -50 dBm to -	+10 dBm)
Modulation (Option 0542	3)		De night	
	Frequency Error	± 10 Hz + time l	pase error, 99% confidence level	
Re	sidual EVM (rms)	2.5% typical (E-l	JTRA Test Model 3.1) (RF Input -	50 dBm to +10 dBm)
Over-the-Air (OTA) Meas	urements (Option	0546)		
	Scanner	Six strongest Syr	nc Signals	
	Auto Save	Yes		
GPS Tag	ging and Logging	Yes		





Fixed and Mobile WiMAX Signal Analyzers (Options 0046, 0047, 0066, 0067, 0037)

Measurement	S
-------------	---

RF (Option 0046 - Fixed) (Option 0066 - Mobile)	Demodulation (Option 0047 - Fixed) (Option 0067 - Mobile)	Over-the-Air (OTA) (Option 0037 - Mobile)	Pass/Fail (User Editable)
Channel Spectrum Channel Power Occupied Bandwidth Power vs. Time Channel Power Preamble Power Downlink Burst Power (Mobile) Uplink Burst Power (Mobile) Data Burst Power (Fixed) Crest Factor (Fixed) ACPR RF Summary	Constellation RCE (RMS/Peak) EVM (RMS/Peak) Frequency Error CINR Base Station ID Sector ID Spectral Flatness Adjacent Subcarrier Flatness EVM vs. Subcarrier/Symbol RCE (RMS/Peak) EVM (RMS/Peak) Frequency Error CINR (Mobile) Base Station ID Sector ID (Mobile)	Channel Power Monitor Preamble Scanner (Six) Preamble Relative Power Cell ID Sector ID PCINR Dominant Preamble Base Station ID	Pass Fail All Pass/Fail RF Pass Fail Demod Measurements Channel Power Occupied Bandwidth Downlink Bust Power Uplink Burst Power Preamble Power Crest Factor Frequency Error Carrier Frequency EVM RCE Sector ID (Mobile)
			Sector 15 (Hobite)

Setup Parameters

Fixed WiMAX Cyclic Prefix Ratio (CP) 1/4, 1/8, 1/16, 1/32

Fixed WiMAX Span 5, 10, 15, 20 MHz

Fixed WiMAX Frame Length 2.5, 5.0, 10.0 msec

Modulation Summary

Mobile WiMAX Zone Type PUS

Mobile WiMAX DL-MAP Auto Decoding Convolutional Coding (CC), Convolutional Turbo Coding (CTC)

Mobile WiMAX Bandwidths 3.50, 5.00, 7.00, 8.75, 10.00 MHz

Mobile WiMAX Cyclic Prefix Ratio (CP) 1/8

Mobile WiMAX Span 5, 10, 20, 30 MHz

Mobile WiMAX Frame Lengths 5, 10 msec

Mobile WiMAX Demodulation Auto, Manual, FCH

Frequency Center, Signal Standard, Channel #, Closest Channel, Decrement/Increment Channel

Amplitude Scale/Division, Power Offset, Auto Range, Adjust Range

Sweep Single/Continuous, Trigger Sweep

Save/Recall Setup, Measurement, Screen Shot (save only), to Internal/External Memory

Measurement Summary Screens Overall Measurements, RF Measurements, Signal Quality Measurements

RF Measurements (Option 0046 - Fixed, Option 0066 - Mobile)

RF Channel Power Accuracy \pm 1.5 dB, \pm 1.0 dB typical, (RF input -50 dBm to +20 dBm)

Demodulated Signal Analyzer (Option 0047 - Fixed, Option 0067 - Mobile)

Fixed Frequency Error ± 0.1 ppm + timebase error, 99% confidence level ± 0.02 ppm + timebase error, 99% confidence level ± 0.02 ppm + timebase error, 99% confidence level 3% typical, 3.5% maximum (RF Input -50 dBm to +20 dBm)

Mobile WiMAX Residual EVM (rms) 2.5% typical, 3.0% maximum, (RF Input -50 dBm to +20 dBm)

Over-the-Air (OTA) Measurements (Option 0037)

Channel Power Monitor Over time (one week), measurement time interval 1 to 60 sec

Preamble Scanner Six Strongest Preambles

Auto Save Yes
GPS Tagging and Logging Yes



TD-SCDMA/HSDPA Signal Analyzers (Options 0060, 0061, 0038)

		Meas	urements	
RF (Option 0060)		nodulation tion 0061)	Over-the-Air (OTA) (Option 0038)	Pass/Fail (User Editable)
Channel Spectrum Channel Power Occupied Bandwidth Left Channel Power Left Channel Occ B/W Right Channel Power Right Channel Occ B/W Power vs. Time Six Slot Powers Channel Power (RRC) DL-UL Delta Power UpPTS Power DwPTS Power On/Off Ratio Slot Peak-to-Average Power Spectral Emission RF Summary	Slot Power DwPTS Pov Noise Floor Frequency Tau Scrambling EVM Peak EVM	SK/16 QAM) ver Error Code Domain Error	Code Scan (32) Scrambling Code Group Tau $E_{\mathcal{C}}/I_0$ Pilot Dominance Tau Scan (Six) Sync-DL# Tau $E_{\mathcal{C}}/I_0$ DwPTS Power Pilot Dominance Record Run/Hold	Pass Fail All Pass/Fail RF Pass Fail Demod Measurements Occupied Bandwidth Channel Power Channel Power RCC On/Off Ratio Peak-to-Average Ratio Frequency Error EVM Peak EVM Peak Code Domain Error Tau Carrier Feedthrough Noise Floor
Setup Parameters	lot Selection	Auto, 0-6		
Scrambling/Mic Max Measure Use	ement Speed er Selectable dulation Type Frequency Amplitude Sweep Save/Recall enery Screens	Auto, 0-31 Auto, 0-127 Auto, 2, 4, 6, 8, Fast, Normal, SI Uplink Switch Po Auto, QPSK, 8 P Center, Signal S Scale/Division, F Hold/Run, Triggo Setup, Measurer Overall Measurer	tandard, Channel #, Closest Chann Power Offset, Auto Range, Adjust R er Sweep ment, Screen Shot (save only), to ments, RF Measurements, Signal C	u Offset nel, Decrement/Increment Channel lange, Units (dBm/Watts) Internal/External Memory Quality Measurements
RF Channel Power Acc	curacy (RRC)	±1.5 dB, ±1.0 c	B typical, (slot power -40 to +10 o	dBm)
• • • • • • • • • • • • • • • • • • • •	d Modulation al EVM (rms) PN Offset	QPSK, 8 PSK, 10 3% typical, P-C Within 1 x 64 ch	CPH slot power > -50 dBm	
Timing Error (Tau) for Domina		± 0.2 μs (extern 1, 16		
Over-the-Air (OTA) Measurer		•		
C	ode Scanner Tau Scanner Auto Save	32 Sync Codes a Six strongest Sy Yes	and associated Scrambling Code Gr nc Codes	roups

GPS Tagging and Logging

General Specifications	All specifications and characteristics apply under the following conditions, unless otherwise stated: 1) After 5 minutes of warm-up time, where instrument is left in the ON state; 2) All specifications apply when using internal reference; 3) All specifications subject to change without noti 4) Typical performance is the measured performance of an average unit; 5) Recommended calibration cycle is 12 months.
Maximum Continuous Input	(≥ 10 dB input attenuation) +30 dBm
Input Damage Level	\geq 10 dB input attenuation, $> +30$ dBm, \pm 50 Vdc
ESD Damage Level	(≥ 10 dB input attenuation) > 10 kV
External Reference Frequencies	1 MHz, 1.2288 MHz, 1.544 MHz, 2.048 MHz, 2.4576 MHz, 4.8 MHz, 4.9152 MHz, 5 MHz 9.8304 MHz, 10 MHz, 13 MHz and 19.6608 MHz at -10 dBm to $+10$ dBm
Setup Parameters	
System	Status (Temperature, Battery Info, S/N, Firmware Ver, IP Address, Options Installed) Self Test, Application Self Test GPS (see Option 0031)
System Options	Name, Date and Time, Ethernet Configuration, Brightness, Volume Language (English, French, German, Spanish, Chinese, Japanese, Korean, Italian, User defined Reset (Factory Defaults, Master Reset, Update Firmware)
File	Save, Recall, Delete, Directory Management
Save/Recall	Setups, Measurements, Screen Shots Jpeg (save only)
Delete	Selected File, All Measurements, All Mode Files, All Content
Directory Management	Sort Method (Name/Type/Date), Ascend/Descend, Internal/USB, Copy, Format USB
Internal Trace/Setup Memory	> 13,000 traces
External Trace/Setup Memory	Limited by size of USB Flash drive or Compact Flash module
Mode Switching	Auto-Stores/Recalls most recently used Setup Parameters in the Mode
Connectors	
RF In	Type N, female, 50 Ω , Maximum Input + 30 dBm, ± 50 VDC
GPS	BNC, female, reverse polarity
External Power	5.5 mm barrel connec <mark>tor, 12 to 15 VDC</mark> , < 5.0 Amps
LAN Connection	RJ48C, 10/100 Mbps, Connect to PC or LAN for Remote Access
Compact Flash Interface	Type I
USB Interface	Type A, Connect Flash Drive and Power Sensor
USB Interface	5-pin mi <mark>ni</mark> -B, Connect to PC for data transfer
Headset	2.5 mm minature phone plug
External Trigger In	BNC, female, 50 Ω , Maximum Input ± 5 VDC
IF Out	BNC, female, 50 Ω, 37.8 MHz
Display	The cour
Size	8.4"
Resolution	800 X 600
Battery	BNC, female, 50 Ω, 37.8 MHz 8.4" 800 x 600 Li-Ion 2.5 hours, typical
Type Rattory Operation	13 E hours trunical
Battery Operation Electromagnetic Compatibility	2.5 hours, typical
European Union	CE Mark, EMC Directive 89/336/EEC, 92/31/EEC, 93/68/EEC and Low Voltage Directive 73/23/EEC, 93/68/EEC
Australia and New Zealand	C-tick N274
Interference	EN 61326-1
Emissions	EN 55011
Immunity	EN 61000-4-2/-4-3/-4-4/-4-5/-4-6/-4-11
Safety	
Safety Class	EN 61010-1 Class 1
Product Safety	IEC 60950-1 when used with Company supplied Power Supply
Environmental	
	10.00 55.00
Operating Temperature	−10 °C to 55 °C
	-10 °C to 55 °C 85%
Operating Temperature	
Operating Temperature Maximum Humidity	85%
Operating Temperature Maximum Humidity Shock	85% MIL-PRF-28800F Class 2
Operating Temperature Maximum Humidity Shock Storage	85% MIL-PRF-28800F Class 2 -51 °C to 71 °C
Operating Temperature Maximum Humidity Shock Storage Altitude	85% MIL-PRF-28800F Class 2 -51 °C to 71 °C


Master Software Tools (for your PC)

Database Management	
Full Trace Retrieval	Retrieve all traces from instrument into one PC directory
Trace Catalog	Index all traces into one catalog
Trace Rename Utility	Rename measurement traces
Group Edit	Titles, subtitles, plot scaling, markers and limit lines, simultaneously on similar files
DAT File Converter	Converts HHST files to MST file format and vice-versa
Data Analysis	
Trace Math and Smoothing	Compare multiple traces
Data Converter	Convert from/to Return Loss/ VSWR/ Cable Loss/ DTF and also into Smith Charts
Measurement Calculator	Translates into other units
Report Generation	
Report Generator	Includes GPS, power level, and calibration status along with measurements
Edit Graph	Change scale, limit lines, and markers
Report Format	Create reports in HTML for PDF format
Export Measurements	Export measurements to *.s2p, *.jpg or *.csv format
Notes	Annotate measurements
Mapping (GPS Required)	
Spectrum Analyzer Mode	MapInfo, MapPoint
Mobile WiMAX OTA Option	Google Earth, Google Maps, MapInfo
Folder Spectrogram (Spectrum Monitoring fo	or Interference Analysis and Spectrum Clea <mark>ring)</mark>
Folder Spectrogram – 2D View	Creates a composite file of multiple traces Peak Power, Total Power, Peak Frequency, Histogram, Average Power (Max/Min) File Filter (Violations over limit lines or deviations from averages) Playback
Video Folder Spectrogram – 2D View	Create AVI file to export for management review/reports
Folder Spectrogram - 3D View	Views (Set Threshold, Markers) - 3D (Rotate X, Y, Z Axis, Level Scale, Signal ID) - 2D View (Frequency or Time Domain, Signal ID)
	 Top Down Playback (Frequency and/or Time Domain)
List/Parameter Editors	
List/Parameter Editors Traces	
	Playback (Frequency and/or Time Domain)
Traces	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers
Traces Antennas, Cables, Signal Standards	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List
Traces Antennas, Cables, Signal Standa <mark>rd</mark> s Product U <mark>pda</mark> tes	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware
Traces Antennas, Cables, Signal Standa <mark>rd</mark> s Product U <mark>pd</mark> ates Firmware Upload	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required)
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages Mobile WiMAX	Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus DL-MAP Parameters
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages Mobile WiMAX Display	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus DL-MAP Parameters Modify display settings
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages Mobile WiMAX Display Script Master™	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus DL-MAP Parameters Modify display settings
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages Mobile WiMAX Display Script Master™ Channel Scanner Mode	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus DL-MAP Parameters Modify display settings Automate scan up to 1200 channels, repeat for sets of 20 channels, repeat all channels
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages Mobile WiMAX Display Script Master™ Channel Scanner Mode GSM/GPRS/EDGE or W-CDMA/HSDPA Mode	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus DL-MAP Parameters Modify display settings Automate scan up to 1200 channels, repeat for sets of 20 channels, repeat all channel Automate Signal Analysis testing requirements with annotated how-to pictures
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages Mobile WiMAX Display Script Master™ Channel Scanner Mode GSM/GPRS/EDGE or W-CDMA/HSDPA Mode Connectivity Connections	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus DL-MAP Parameters Modify display settings Automate scan up to 1200 channels, repeat for sets of 20 channels, repeat all channel Automate Signal Analysis testing requirements with annotated how-to pictures Connect to PC using USB, LAN, or Direct Ethernet connection
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages Mobile WiMAX Display Script Master™ Channel Scanner Mode GSM/GPRS/EDGE or W-CDMA/HSDPA Mode Connectivity Connections Download	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus DL-MAP Parameters Modify display settings Automate scan up to 1200 channels, repeat for sets of 20 channels, repeat all channel Automate Signal Analysis testing requirements with annotated how-to pictures Connect to PC using USB, LAN, or Direct Ethernet connection Download measurements and live traces to PC for storage and analysis
Traces Antennas, Cables, Signal Standards Product Updates Firmware Upload Pass/Fail VSG Pattern Converter Languages Mobile WiMAX Display Script Master™ Channel Scanner Mode GSM/GPRS/EDGE or W-CDMA/HSDPA Mode Connectivity Connections	Playback (Frequency and/or Time Domain) Add, delete, and modify limit lines and markers Modify instrument's Antenna, Cable, and Signal Standard List Auto-checks Anritsu website for latest revision firmware Upload new firmware into the instrument Create, download, or edit Signal Analysis Pass/Fail Limits Import user-defined patterns (ASCII text or MATLAB file format required) Add up to two languages or modify non-English language menus DL-MAP Parameters Modify display settings Automate scan up to 1200 channels, repeat for sets of 20 channels, repeat all channel Automate Signal Analysis testing requirements with annotated how-to pictures Connect to PC using USB, LAN, or Direct Ethernet connection


Ordering Information

		MS2723B	Description
	millim	9 kHz to 13 GHz	Spectrum Analyzer
		Options	
		MS2723B-0031	GPS Receiver (includes antenna)
	+-	MS2723B-0019	High-Accuracy Power Meter
		MS2723B-0025	Interference Analyzer
	lutalil	MS2723B-0027	Channel Scanner
		MS2723B-0089	Zero-Span IF Output
		MS2723B-0090	Gated Sweep
		MS2723B-0009	I/Q Demodulation Hardware*
	G	MS2723B-0040	GSM/GPRS/EDGE RF Measurements*
		MS2723B-0041	GSM/GPRS/EDGE Demodulation*
		MS2723B-0044	W-CDMA/HSDPA RF Measurements*
	L.M.	MS2723B-0045	W-CDMA Demodulation*
		MS2723B-0065	W-CDMA/HSDPA Demodulation*
		MS2723B-0035	W-CDMA/HSDPA Over-the-Air Measurements**
		MS2723B-0060	TD-SCDMA/HSDPA Measurements*
	TOS	MS2723B-0061	TD-SCDMA/HSDPA Demodulation*
	lns	MS2723B-0038	TD-SCDMA/HSDPA Over-the-Air Measurements*
			o' with
		MS2723B-0541	LTE RF Measurements*
	LITE	MS2723B-0542	LTE Modulation Measurements*
		MS2723B-0546	LTE Over-the-Air Measurements*
100	2	orne 1	
		MS2723B-0042	cdmaOne/CDMA2000 1X RF Measurements*
	C	MS2723B-0043	cdmaOne/CDMA2000 1X Demodulation*
		MS2723B-0033	cdmaOne/CDMA2000 1X Over-the-Air Measurements**
		el Occ	
	2000	MS2723B-0062	CDMA2000 1xEV-DO RF Measurements*
	EN	MS2723B-0063	CDMA2000 1xEV-DO Demodulation*
	cec will	MS2723B-0034	CDMA2000 1xEV-DO Over-the-Air Measurements**
	A SHO		
131	N. W.	MS2723B-0046	IEEE 802.16 Fixed WiMAX RF Measurements*
On	(a) f	MS2723B-0047	IEEE 802.16 Fixed WiMAX Demodulation*
in			
	paramag	MS2723B-0066	IEEE 802.16 Mobile WiMAX RF Measurements*
	_ MW _	MS2723B-0067	IEEE 802.16 Mobile WiMAX Demodulation*
		MS2723B-0037	IEEE 802.16 Mobile WiMAX Over-the-Air Measurements
		MS2723B-0098	Standard Calibration to Z540
		MS2723B-0099	Premium Calibration to Z540 plus test data
			*Requires Option 0009, **Requires Option 0009, and Option 0031

Power Sensors (For complete ordering information see the respective datasheets of each sensor)




Manuals (soft copy included on MST CD and at www.us.anritsu.com)



MS2723B	Description
10580-00175	Spectrum Master User Guide (Hard copy included) - Bias-Tee, GPS Receiver
10580-00231	Spectrum Analyzer Measurement Guide - Interference Analyzer, Channel Scanner, IF Output, Gated Sweep
10580-00240	Power Meter Measurement Guide - High Accuracy Power Meter
10580-00232	Signal Generator Measurement Guide - CW, Tracking, and Vector Signal Generator
10580-00234	3GPP Signal Analyzer Measurement Guide - GSM/EDGE, W-CDMA/HSDPA, TD-SCDMA/HSDPA, LTE
10580-00235	3GPP2 Signal Analyzer Measurement Guide - CDMA, EV-DO
10580-00236	WiMAX Signal Analyzer Measurement Guide - Fixed WiMAX, Mobile WiMAX
10580-00176	Programming Manual
10580-00177	Maintenance Manual

Troubleshooting Guides (soft copy included on MST CD and at www.us.anritsu.com)



11410-00472	Interference
11410-00466	GSM/GPRS/EDGE Base Stations
11410-00463	W-CDMA/HSDPA Base Stations
11410-00465	TD-SCDMA/HSDPA Base Stations
11410-00467	cdmaOne/CDMA2000 1X Base Stations
11410-00468	CDMA2000 1xEV-DO Base Stations
11410-00470	Fixed WiMAX Base Stations
11410-00469	Mobile WiMAX Base Stations

Standard Accessories (included with instrument)



2300-498 Spectrum Master User Guide (includes Bias-Tee and GPS Receiver)
MST CD: Master Software Tools, User/Measurement Guides,
Programming Manual, Troubleshooting Guides, Application Notes
Soft Carrying Case
Tilt Bail Stand Accessory

64343 Tilt Bail Stand Accessory

633-44 Rechargeable Li-Ion Battery
40-168-R AC/DC Power Supply
806-141-R Automotive Cigarette Lighter 12 Volt DC Adapter

3-806-152 Cat 5e Crossover Patch Cable, 7 feet/213 cm
2000-1371-R Ethernet Cable, 7 feet/213 cm
3-2000-1498 USB A-mini B Cable, 10 feet/305 cm
2000-1520-R USB Memory Drive
1091-27-R Type-N male to SMA female adapter
1091-172 Type-N male to BNC female adapter

11410-00406 Spectrum Master™ MS2723B Technical Data Sheet One Year Warranty (Including battery, firmware, and software) Certificate of Calibration and Conformance

Optional Accessories

Directional Antennas



Part Number	Description
2000-1411-R	824 MHz to 896 MHz, N(f), 10 dBd, Yagi
2000-1412-R	885 MHz to 975 MHz, N(f), 10 dBd, Yagi
2000-1413-R	1710 MHz to 1880 MHz, N(f), 10 dBd. Yagi
2000-1414-R	1850 MHz to 1990 MHz, N(f), 9.3 dBd, Yagi
2000-1415-R	2400 MHz to 2500 MHz, N(f), 10 dBd, Yagi
2000-1416-R	1920 MHz to 2170 MHz, N(f), 10 dBd, Yagi
2000-1519-R	500 MHz to 3000 MHz, log periodic
2000-1617	600 MHz to 21000 MHz, N(f), 5-8 dBi to 12 GHz, 0-6 dBi to 21 GHz, log periodic

Portable Antennas



2000-1200	806 MHz to 866 MHz, SMA(m), 50 Ω
2000-1473	870 MHz to 960 MHz, SMA(m), 50 Ω
2000-1035	896 MHz to 941 MHz, SMA (m), 50 Ω (1/4 wave)
2000-1030	1710 MHz to 1880 MHz, SMA(m), 50 Ω (1/2 wave)
2000-1474	1710 MHz to 1880 MHz with knuckle elbow (1/2 wave)
2000-1031	1850 MHz to 1990 MHz, SMA(m), 50 Ω (1/2 wave)
2000-1475	1920 MHz to 1980 MHz and 2110 MHz to 2170 MHz, SMA(m), 50 Ω
2000-1032	2400 MHz to 2500 MHz, SMA(m), 50 Ω (1/2 wave)
2000-1361	2400 MHz to 2500, 5000 MHz to 6000 MHz, SMA(m), 50 Ω
2000-1616	20 MHz to 21000 MHz, N(f), 50 Ω
61532	Antenna Kit (Consists of: 2000-1030, 2000-1031, 2000-1032-R, 2000-1200, 2000-1035, 2000-1361, and carrying pouch)

Bandpass Filters



	5-0 CO.
1030-114-R	806 MHz to 869 MHz, N(m) to SMA(f), 50 Ω
1030-109-R	824 MHz to 849 MHz, N(m) to SMA (f), 50 Ω
1030-110-R	880 MHz to 915 MHz, N(m) to SMA (f), 50 Ω
1030-105-R	890 MHz to 915 MHz Band, 0.41 dB loss, N(m) to SMA(f), 50 Ω
1030-111-R	1850 MHz to 1910 MHz, N(m) to SMA (f), 50 Ω
1030-106-R	1710 MHz to 1790 MHz Band, 0.34 dB loss, N(m) to SMA(f), 50 Ω
1030-107-R	1910 MHz to 1990 MHz Band, 0.41 dB loss, N(m) to SMA(f), 50 Ω
1030-112-R	2400 MHz to 2484 MHz, N(m) to SMA (f), 50 Ω
1030-155-R	2500 MHz to 2700 MHz, N(m) to N(f), 50 Ω
0.	

Attenuators





Yes and the second	
3-1010-122	20 dB, 5 W, DC to 12.4 GHz, N(m) to N(f)
42N50-20	20 dB, 5 W, DC to 18 GHz, N(m) to N(f)
42N50A-30	30 dB, 5 W, DC to 18 GHz, N(m) to N(f)
3-1010-123	30 dB, 50 W, DC to 8.5 GHz, N(m) to N(f)
1010-127-R	30 dB, 150 W, DC to 3 GHz, N(m) to N(f)
3-1010-124	40 dB, 100 W, DC to 8.5 GHz, N(m) to N(f), Uni-directional
1010-121	40 dB, 100 W, DC to 18 GHz, N(m) to N(f), Uni-directional
1010-128-R	40 dB, 150 W, DC to 3 GHz, N(m) to N(f)

Optional Accessories (continued)

Adapters	
1091-26-R	SMA(m) to N(m), DC to 18 GHz, 50 Ω
1091-27-R	SMA(f) to N(m), DC to 18 GHz, 50 Ω
1091-80-R	SMA(m) to N(f), DC to 18 GHz, 50 Ω
1091-81-R	SMA(f) to N(f), DC to 18 GHz, 50 Ω
1091-172	BNC(f) to N(m), DC to 1.3 GHz, 50 Ω
1091-379-R	7/16 DIN(f) to 7/16 DIN(f), DC to 6 GHz, 50 $\Omega,$ w/ Reinforced Gr
510-102-R	$N(m)$ to $N(m),DC$ to 11 GHz, 50 $\Omega,90$ degrees right angle
Precision Adapters	
34NN50A	Precision Adapter, N(m) to N(m), DC to 18 GHz, 50 Ω
34NFNF50	Precision Adapter, N(f) to N(f), DC to 18 GHz, 50 Ω
Miscellaneous Accessories	
2000-1410	GPS Antenna, RP-BNC
69793	CW Signal Generator Kit
2000-1520-R	USB Flash Drive
3-200-1567	512 MB Compact Flash Card
2000-1374	External Charger for Li-lon Batteries
Backpack and Transit Case	
67135	Anritsu Backpack (For Handheld Instrument and PC)
760-243-R	Large Transit Case with Wheels and Handle
And Issue	Sale of Rental Com





Anritsu Corporation

5-1-1 Onna, Atsugi-shi, Kanagawa, 243-8555 Japan Phone: +81-46-223-1111

Fax: +81-46-296-1264

• U.S.A.

Anritsu Company

1155 East Collins Boulevard, Suite 100, Richardson, Texas 75081 U.S.A. Toll Free: 1-800-ANRITSU (267-4878) Phone: +1-972-644-1777 Fax: +1-972-671-1877

Canada

Anritsu Electronics Ltd.

700 Silver Seven Road, Suite 120, Kanata, Ontario K2V 1C3, Canada Phone: +1-613-591-2003 Fax: +1-613-591-1006

• Brazil

Anritsu Electrônica Ltda.

Praca Amadeu Amaral, 27-1 Andar 01327-010 - Paraiso, São Paulo, Brazil Phone: +55-11-3283-2511 Fax: +55-11-3288-6940

Mexico

Anritsu Company, S.A. de C.V.

Av. Ejército Nacional No. 579 Piso 9, Col. Granada 11520 México, D.F., México Phone: +52-55-1101-2370 Fax: +52-55-5254-3147

U.K.

Anritsu EMEA Ltd.

200 Capability Green, Luton, Bedfordshire LU1 3LU, U.K. Phone: +44-1582-433200 Fax: +44-1582-731303

France Anritsu S.A.

16/18 Avenue du Québec-SILIC 720 91961 COURTABOEUF CEDEX, France Phone: +33-1-60-92-15-50

Fax: +33-1-64-46-10-65

Germany Anritsu GmbH

Nemetschek Haus Konrad-Zuse-Platz 1 81829 München, Germany Phone: +49 (0) 89 442308-0 Fax: +49 (0) 89 442308-55

different for Sall Anritsu AB
Borgafjordsgatan 13, 164 40 Kista, Sweden
Phone: +46-8-534-707-30
Finland
Anritsu AB
eknobuler

Phone: +358-20-741-8100 Fax: +358-20-741-8111

Denmark

Anritsu A/S

Kirkebjerg Allé 90 DK-2605 Brøndby, Denmark Phone: +45-72112200 Fax: +45-72112210

Spain

Anritsu EMEA Ltd.

Oficina de Representación en España

Edificio Veganova Avda de la Vega, nº 1 (edf 8, pl1, of 8) 28108 ALCOBENDAS - Madrid, Spain Phone: +34-914905761 Fax: +34-914905762

Russia

Anritsu EMEA Ltd.

Representation Office in Russia

Tverskaya str. 16/2, bld. 1, 7th floor. Russia, 125009, Moscow Phone: +7-495-363-1694 Fax: +7-495-935-8962

United Arab Emirates Anritsu EMEA Ltd.

Dubai Liaison Office

P O Box 500413 - Dubai Internet City Al Thuraya Building, Tower 1, Suite 701, 7th Floor Dubai, United Arab Emirates Phone: +971-4-3670352 Fax: +971-4-3688460

Singapore

Anritsu Pte. Ltd.

60 Alexandra Terrace, #02-08, The Comtech (Lobby A) Singapore 118502 Phone: +65-6282-2400 Fax: +65-6282-2533

India

Anritsu Pte. Ltd.

India Branch Office

3rd Floor, Shri Lakshminarayan Niwas, #2726, 80 ft Road, HAL 3rd Stage, Bangalore - 560 075, India Phone: +91-80-4058-1300 Fax: +91-80-4058-1301

· P. R. China (Hong Kong)

Anritsu Company $\bar{L}td$.

Units 4 & 5, 28th Floor, Greenfield Tower, Concordia Plaza, No. 1 Science Museum Road, Tsim Sha Tsui East, Kowloon, Hong Kong, P.R. China Phone: +852-2301-4980

Fax: +852-2301-3545 • P. R. China (Beijing)

Anritsu Company Ltd.

Beijing Representative Office

Room 2008, Beijing Fortune Building, No. 5, Dong-San-Huan Bei Road, Chao-Yang District, Beijing 100004, P.R. China Phone: +86-10-6590-9230

Fax: +86-10-6590-9235

Korea Anritsu Corporation, Ltd.

8F Hyunjuk Bldg. 832-41, Yeoksam-Dong, Kangnam-ku, Seoul, 135-080, Korea Phone: +82-2-553-6603 Fax: +82-2-553-6604

Australia

Anritsu Pty Ltd.

Unit 21/270 Ferntree Gully Road, Notting Hill Victoria, 3168, Australia Phone: +61-3-9558-8177

Fax: +61-3-9558-8255 Taiwan

Anritsu Company Inc.

7F, No. 316, Sec. 1, Neihu Rd., Taipei 114, Taiwan

Phone: +886-2-8751-1816 Fax: +886-2-8751-1817

